



expotent premium 2 x 2 m			
Item Nr.*	Sparepart	Art. Nr.	
5	Expotent Sparepart Basic/Premium Pushbutton	60005	
1	Expotent Sparepart Premium Outerleg Corner 163,5cm	60027	
2	Expotent Sparepart Premium Innerleg Corner 130cm	60028	
3	Expotent Sparepart Premium 2-way Bracket for Outerleg Corner	60030	
4	Expotent Sparepart Premium 2-way Glider for Outerleg Corner	60032	
6	Expotent Sparepart Premium Scissorprofile 95cm	60033	
7	Expotent Sparepart Premium 3-way Connector	60038	
8	Expotent Sparepart Premium Screw for Scissors	60039	
9	Expotent Sparepart Premium Screw with Captive Nut	60040	
10	Expotent Sparepart Premium Peakpole 2x2m, 3x2m (2-parts)	60041	
11	Expotent Sparepart Premium Peakpole Closure Cap	60046	
w/drawing	Expotent Sparepart Cord	60021	
w/drawing	Expotent Sparepart Peg	60022	
w/drawing	Expotent Sparepart Premium 4-way Bracket for Peakpole	60047	
w/drawing	Expotent Sparepart Premium 4-way Glider for Peakpole	60048	
w/drawing	Expotent Sparepart Premium Plasticlead	60049	
w/drawing	Expotent Sparepart Premium Bag for Frame 2x2m	60182	
w/drawing	Expotent Sparepart Premium Innerleg Corner 150cm (Ext.)	60171	
w/drawing	Expotent transport-wheels-system	60176	