



| expotent premium 3 x 2 m | | | |
|--------------------------|--|----------|--|
| Item Nr.* | Sparepart | Art. Nr. | |
| 5 | Expotent Sparepart Basic/Premium Pushbutton | 60005 | |
| 1 | Expotent Sparepart Premium Outerleg Corner 163,5cm | 60027 | |
| 2 | Expotent Sparepart Premium Innerleg Corner 130cm | 60028 | |
| 3 | Expotent Sparepart Premium 2-way Bracket for Outerleg Corner | 60030 | |
| 4 | Expotent Sparepart Premium 2-way Glider for Outerleg Corner | 60032 | |
| 6 | Expotent Sparepart Premium Scissorprofile 95cm | 60033 | |
| 7 | Expotent Sparepart Premium 3-way Connector | 60038 | |
| 8 | Expotent Sparepart Premium Screw for Scissors | 60039 | |
| 9 | Expotent Sparepart Premium Screw with Captive Nut | 60040 | |
| 10 | Expotent Sparepart Premium Peakpole 2x2m, 3x2m (2-parts) | 60041 | |
| 11 | Expotent Sparepart Premium Peakpole Closure Cap | 60046 | |
| w/o drawing | Expotent Sparepart Cord | 60021 | |
| w/o drawing | Sparepart Peg | 60022 | |
| w/o drawing | Expotent Sparepart Premium 4-way Bracket for Peakpole | 60047 | |
| w/o drawing | Expotent Sparepart Premium 4-way Glider for Peakpole | 60048 | |
| w/o drawing | Expotent Sparepart Premium Plasticlead | 60049 | |
| w/o drawing | Expotent Sparepart Premium Bag for Frame 3x2m | 60184 | |
| w/o drawing | Expotent Sparepart Premium Innerleg Corner 150cm (Ext.) | 60171 | |
| w/o drawing | Expotent transport-wheels-system | 60177 | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |