




expotent premium 4,5 x 3 m			
Item Nr.*	Sparepart	Art. Nr.	
5	Expotent Sparepart Basic/Premium Pushbutton	60005	
1	Expotent Sparepart Premium Outerleg Corner 163,5cm	60027	
2	Expotent Sparepart Premium Innerleg Corner 130cm	60028	
3	Expotent Sparepart Premium 2-way Bracket for Outerleg Corner	60030	
4	Expotent Sparepart Premium 2-way Glider for Outerleg Corner	60032	
6	Expotent Sparepart Premium Scissorprofile 143,8cm	60035	
7	Expotent Sparepart Premium 3-way Connector	60038	
8	Expotent Sparepart Premium Screw for Scissors	60039	
9	Expotent Sparepart Premium Screw with Captive Nut	60040	
10	Expotent Sparepart Premium Peakpole 3x3m, 4,5x3m, 6x3m (2-parts)	60043	
11	Expotent Sparepart Premium Peakpole Closure Cap	60046	
w/o drawing	Expotent Sparepart Cord	60021	
w/o drawing	Sparepart Peg	60022	
w/o drawing	Expotent Sparepart Premium 4-way Bracket for Peakpole	60047	
w/o drawing	Expotent Sparepart Premium 4-way Glider for Peakpole	60048	
w/o drawing	Expotent Sparepart Premium Plasticlead	60049	
w/o drawing	Expotent Sparepart Premium Bag for Frame 4,5x3m	60187	
w/o drawing	Expotent Sparepart Premium Innerleg Corner 150cm (Ext.)	60171	
w/o drawing	Expotent transport-wheels-system	60177	